AMINOGram
Bioimpedance & Innovation

MEASUREMENT PROCEDURE





Place the 1st electrode at the base of the fingers (RED clip) and the 2nd at the wrist crease, at least 5 cm away.



Place the 1st electrode at the base of the toes (RED clip) and the 2nd 5, 6 or 7 cm away depending on foot size (small, medium, large).



Connect the cable to the "hand" port.
The RED clip must be oriented towards the fingers.



Connect the cable to the "foot" port. The RED clip must be oriented towards the toes.



Remain motionless until the measurement is complete.

⚠ **For repeatable measurements, always place the electrodes in the same location each time you measure the same patient.**