AMINOGram
Bioimpedance & Innovation

MEASUREMENT PROCEDURE





Moisten the electrodes, heel, and fingers.



2–3 fingers on the back electrode + thumb on the front.



Bend the leg and lift the heel.



Limbs must not touch each other.



Place the device under the malleoli.



Measurement starts automatically (10 s).